



HOW TO CONFIGURE THE TECHNICAL SETTINGS

ENTER IN THE TECHNICAL SETTINGS PROGRAMMING

1 - PRESS AND HOLD FOR 5 SECONDS




2 - PRESS TO ENTER



AUTOREFILL WITH PUMP


Light ON = Pump Enable
Light OFF = Pump Disable

3 - PRESS TO ENABLE OR DISABLE



MODIFY THE KEY LIGHT INTENSITY


4 - PRESS TO CHANGE THE KEY LIGHT INTENSITY



ENABLE THE SOFTWARE BLOCK

Light ON = Software blocked
Light OFF = Software unblocked


5 - PRESS TO ENABLE OR DISABLE



ENABLE THE PUMP DURING DELIVERY OF HOT WATER

Light ON = Pump On during delivery of hot water
Light OFF = Pump OFF during delivery of hot water


6 - PRESS TO ENABLE OR DISABLE



ENABLE THE CUPWARMER


Light ON = Cup Warmer ON
Light OFF = Cup Warmer OFF

7 - PRESS TO ENABLE OR DISABLE



GO OUT FROM THE TECHNICAL SETTING PROGRAMMING

8 - PRESS TO SAVE AND EXIT



GO OUT FROM PROGRAMMING

9 - PRESS TO SAVE AND EXIT



Special Settings


RESTORE THE DEFAULT SETTINGS

Machine in OFF status.

POWER ON THE MACHINE

+

PRESS AND HOLD FOR 5 SECONDS



UNLOCK THE SOFTWARE APPIA LIFE 2-3GR-COMPACT-XT

Machine in OFF status.

POWER ON THE MACHINE

+

PRESS AND HOLD FOR 5 SECONDS



UNLOCK THE SOFTWARE APPIA LIFE 1GR

Machine in OFF status.

POWER ON THE MACHINE

+

PRESS AND HOLD FOR 5 SECONDS

